

**A**

AFCS Operation 39  
Airspeed Indicator 14  
Altimeter 18–19  
Altitude Alerting 19  
Altitude Hold Mode (ALT) 50  
Approach Mode 62  
Attitude and Heading Reference System (AHRS) 6, 7  
Attitude Indicator 16  
Automatic Reversion 54  
Autopilot 39  
Autopilot Disconnect 42

**B**

Barometric setting, Altimeter 17–18, 19–20  
Bearing Pointers 27

**C**

Command Bars 46

**D**

Display  
  Overview 3

**E**

Electronic Stability & Protection 40

**F**

Flight Director 39  
Flight Level Change Mode 52

**G**

GFC 500 35  
Glidepath Mode (GP) 55  
GMC 507 36  
GSA 28 36

**H**

Heading Select Mode 59, 60  
Heading Strip 20  
Horizontal Situation Indicator (HSI) 28

**I**

Integrated Autopilot  
  Disengaging 42  
  Engaging 42

**M**

Manual Electric Trim 40  
MENU Key 4  
Menus 8, 9, 11  
Messages  
  Miscellaneous 10, 11, 67, 68

**N**

Navigation Mode 61–62  
NRST Key 4

**P**

Pitch Hold Mode 48

**R**

Roll Hold Mode 58

**S**

- Secure Digital (SD) Cards 4
  - Installing 4
- Selected Altitude 48, 49, 51
- Selected Altitude Capture Mode 48, 49, 51, 57
- Selected Heading 28, 59, 60
- System
  - Annunciations 5
  - Functionality 8
  - Initialization 5

**T**

- Takeoff Mode 56

**V**

- Vertical Deviation Indicator (VDI) 30
- Vertical Speed Indicator (VSI) 22, 29
- Vertical Speed Mode 51

**Y**

- Yaw Damper 40





Garmin International, Inc.  
1200 East 151st Street  
Olathe, Kansas 66062, U.S.A.

Garmin AT, Inc.  
2345 Turner Road SE  
Salem, OR 97302, U.S.A.

Garmin (Europe) Ltd.  
Liberty House, Hounsdown Business Park  
Southampton, Hampshire SO40 9LR U.K.

Garmin Corporation  
No. 68, Zhangshu 2nd Road  
Xizhi District, New Taipei City, Taiwan

**Contact Garmin Product Support at**  
**[www.flygarmin.com](http://www.flygarmin.com)**