

A

Access code	314
Activate a Flight Plan	208
Active channel	541
Active database	584, 585
Active frequency	100, 109
ADS-B	402, 425
AFCS status annunciation	49
AFCS Status Box	433
AHRS	574
Aircraft alerts	562
Air Data Computer	1
Airport	
Information	169
Nearest	39
Airspace alerts	184
Airspace Alerts	184
Airspeed indicator	50
Airspeed Reference	440, 477
Airways	
Collapsed	222
Expanded	222
Alerting system	561
Alerting System	563
Alert levels	562
Alerts	561
Airspace	36
Arrival	37
Audio voice	37
Alerts window	73
Along Track Offset	214
ALT	271
Altimeter	53
Altitude	
Constraints	258
Altitude alerting	76
Altitude buffer	36
Altitude capture	446
Altitude constraints	225
Altitude hold	9
Altitude Hold	9
Altitude Hold Mode (ALT)	437
Altitude Reference	437, 438, 446
ALT knob	9
Ammeter	84–85, 91–92
Annunciations	
Test tone	41
Annunciations, G1000 System	17, 563
Annunciation window	49
AOPA Airport Directory	312, 536, 537, 538, 588
AP	9, 578
Approach	600

Activating	238
ILS	470
Loading	206, 235, 237
Missed	474
Removing	238
WAAS	472
Approach box	522
Approach Mode, AFCS	470, 472
Approach Mode (GPS, VAPP, LOC)	456
APR softkey	237, 243
Arrival Alerts	37
Arrival procedure	190, 204, 232, 233, 234, 256, 258, 267
Attitude	1
Attitude and Heading Reference System (AHRS)	13, 15–16
Attitude indicator	52
Audio alerting system	561
Audio Panel	15
Audio panel controls	
SPKR	125
Audio panel fail-safe operation	131
Aural alerts	566
Automatic audio muting	544
Automatic Dependent Surveillance - Broadcast	402
Automatic Flight Control System (AFCS)	429–478
Alerts	578
Alerts and annunciations	477–478
Controls	430–431
Example procedures	461–468
Status Box	433
Automatic squelch	108
Autopilot	429, 459–460, 578
Autopilot disconnect	431, 450, 460
Auto-tuning	116
Auto-tuning, COM	103
Auto-tuning, NAV	112
Auto Zoom	138
Auxiliary Pages (AUX)	32
AUX - system status page	496, 498, 517, 518, 533, 534, 535, 537
Aviation Symbols	149, 190

B

Backcourse Mode	458
Backlighting	14, 44, 45
Barometric altimeter setting	54
Battery current	84–85, 91–92
Bearing/distance, measuring	143
Bearing information	49, 61
Bearing pointer	60
Bearing source	61
Bus voltage	84, 91

C

Calibrated Airspeed	240
CAUTION	562
CDI	234, 247, 258, 266, 273, 575
CELL MOV Softkey	295
Chart Not Available	500, 520
Chart options	508, 527
Chart setup box	514, 531
ChartView	479, 499, 517
ChartView database	517
ChartView functions	499
ChartView plan view	509
ChartView profile view	510
ChartView softkeys	499
Checklists	547–548
Checklist softkeys	547
CLD TOP Softkey	293, 329
Clearance recorder	128
Closest Point	222
CLR	8
CNS system	95
COM channel spacing	107
COM frequency box	100
Command Bars, flight director	434
COM radio	
Channel spacing	39
COM tuning failure	131
Controls	7
AFCS	430–431
Softkeys	17–20
Control Wheel Steering (CWS)	431, 460
Copy a Flight Plan	209
Course deviation indicator	62
Course Deviation Indicator (CDI)	39
Course To Altitude	239
Cylinder Head Temperature (CHT)	83–85, 86–89

D

Data Bar fields, MFD	38
Databases	13, 583
Database Synchronization	584, 588, 589, 590
Data link	1
Datalink receiver troubleshooting	557
Data logging	551
Date and time	35
Day/Night views	514, 531
Day view	514, 515, 531, 532
DB Mismatch	583
Dead reckoning	78
Dead Reckoning Mode	78
Decision height (DH)	49, 77
Declutter, display	79
Delete a Stored Flight Plan	209

Deleting an entire airway	211, 212
Deleting an entire procedure	211, 212
Deleting an individual waypoint	210, 211
Deleting Flight Plan Items	210
Density Altitude	242
Departure	
Select	229, 232, 235, 238
Timer	42
Departure procedure	202, 216, 229, 231
Departure Time	240
Digital audio entertainment	4
Dilution of Precision (DOP)	26
Direct-to	162, 185, 186, 187, 188, 189, 223, 224, 256, 258, 273
Display backup	15, 99, 131
DME	
HOLD mode	118
NAV1 mode	118
DME information	49, 60, 61
DME transceiver pairing	118
DME tuning window	118
Dual navigation database	585

E

ECHO TOP Softkey	292
Electronic checklists	479–480, 547, 548, 549
Emergency checklist	548
Emergency frequency	131
Engine Display (EIS)	83–85
Engine hours	84, 90–92
Engine Indication System (EIS)	81–94
Engine Leaning Assist	86, 88, 89
Engine manifold pressure	83–85, 87–89, 91–93
Entering flight ID	119
Entertainment audio	129
Entertainment inputs	129
Estimated Position Error (EPE)	26
Ethernet	2
Exhaust Gas Temperature (EGT)	83–84, 86–89

F

Fail-safe operation	131
FD	9, 578
Field of View (SVS)	160
FLC	9
Flight Data Logging	479, 550
Flight director	429, 432–433
Pitch modes	435–441
Roll modes	451
Flight instruments	47, 50
Flight level change	9
Flight Level Change Mode	468
Flight Level Change Mode (FLC)	440, 466, 477

Flight plan	
Closest point to reference	222
Storing	600
Flight plan import/export messages	577
Flight timer	42
FliteCharts	479, 519
FliteCharts®	479
FliteCharts cycle	534
FliteCharts expiration	534
FliteCharts functions	519
FPA	225, 263
Frequency	
Nearest	181
Frequency spacing	107
Frequency toggle key	8
Frequently asked questions	599
Fuel	
Calculations	90–92
Efficiency	242
Endurance	242
Flow	83–85, 87–89, 91–93
Quantity	84–86, 87–88, 91–92
Remaining	91–92, 242
Required	242
Used	91–92
Fuel on Board	242
Fuel Statistics	242

G

GDC 74A	1
GDL 69/69A	1, 278
GDL 90	423
GDU 1040	1
GEA 71	1
geodetic sea level	364, 372, 381
GFC 700 AFCS	429–478
GIA 63	1
Glidepath	271
Glidepath indicator	56
Glidepath Mode (GP)	447, 456, 472
Glideslope	271
Glideslope indicator	49, 56
Glideslope Mode (GS)	431, 449, 470
Global Positioning System (GPS)	
Navigation	185–276
Receiver information	25–27
GMA 1347	1, 44
GMU 44	1
Go Around Mode (GA)	431, 450, 474–475
GPS Window	589
Groundspeed	43
GRS 77	1
GSL	364, 372, 381

GTX 33	1, 3
GTX 33 Transponder	119

H

Heading Select	8, 9
Heading Select Mode (HDG)	453, 462
HI SENS	117
Horizontal situation indicator	57
HSI double green arrow	109
HSI magenta arrow	109
HSI single green arrow	109

I

ID indicator	111
ILS approach	470
Indicated airspeed	50
Indicated Altitude	240
INFO box	523
Inset map	49
Inset Map	18, 22
Intercom system (ICS)	129
Intercom volume and squelch	127
Intersection	
Information	170–171
Inverting a flight plan	209
IOI	378, 388, 579, 580

J

Jeppesen aviation database	583
----------------------------	-----

K

Key(s)	9
--------	---

L

Land Symbols	148
Lean Display (EIS)	86–89
Lightning	22
LNAV	247
Log file	551
Logging data	550
LO SENS	117
LPV	247, 273
LPV approach	461

M

Magnetometer	1
Manual Electric Trim (MET)	429, 431, 459
Map pages	31
Map Panning	140
Map symbols	605
Marker beacon	117
Marker beacon annunciations	49, 74

MASQ processing	95
Measurement units, changing displayed	35
Menus	29
Message advisories	562, 566, 567, 568, 569, 570, 571, 572, 573, 574, 575, 576, 577
MET	578
MFD Data Bar fields	38
Minimum descent altitude (MDA)	49, 77
Minimums	566
Missed Approach	190, 239, 244, 247, 273, 474
Mistrim	578
MKR/MUTE	117
Mode S	119, 120
Mode selection softkeys	120, 123
Morse code identifier	111
Multi Function Display (MFD)	
Softkeys	21

N

National Weather Service	304
Navigation database	225, 226, 568
Navigation Map	187
Navigation Mode, AFCS	464–465
Navigation mode selection	109
Navigation Mode (VOR, GPS, LOC, BC)	454
Navigation source	62–63
NAV radio selection	109
Nearest	
Airports	39, 181–184
VOR	181–182
nearest airport	166, 167, 168
Nearest Airport	166, 167, 168, 169, 237
Minimum Runway Length	169
Surface Matching	169
Nearest Airports Page	167, 168, 169
Nearest Pages (NRST)	33
NEXRAD	18, 22
NEXRAD Softkey	288, 326, 351
Night view	514, 515, 531, 532
Non-path descent	445, 468–469
Normal display operation	14
Normal operating mode	14

O

OBS mode	67
Obstacles	568, 571
Odometer	43
Oil pressure	83–85, 91–93
Oil temperature	83–85, 91–93
Omni Bearing Selector (OBS)	600–601
Other Statistics	240, 242
Outside air temperature	69
Overspeed protection, autopilot	477
Overview	1

P

Parallel Track	215, 216
Passenger address	128
PA system	128
PIREP	338
Pitch hold	9
Pitch Hold Mode (PIT)	436, 477
Pitch modes, flight director	435–441
Pitch Reference	436
Power-up page	547
Power-up, system	13
Presets	543
Primary Flight Display (PFD)	
Softkeys	17–19
Procedure examples, AFCS	461–468
Profile Path	370
Profile View	369

Q

Quick tuning 121.500 MHz	102
--------------------------	-----

R

Radio volume level	111
RAIM	234, 244, 245, 246
Range	158
Receiver Autonomous Integrity Monitoring (RAIM)	27–28, 244
Recorded data	551
Register	314
Required Vertical Speed	264
Required Vertical Speed Indicator	264
Reversionary display operation	14
Reversionary mode	131
ROC	378, 388, 579, 580
Roll Hold Mode (ROL)	431, 452
Roll modes, flight director	451–454
Roll Reference	452
RS-232	3
RS-485	3
Runway	
Minimum length	40
Surface	40
RVSI	264, 265
RX indicator	101

S

SafeTaxi	479, 493, 496
SafeTaxi®	479
SafeTaxi database	497
SBAS	244, 245, 246, 571, 573, 597, 599
Scheduler	479–480, 545
Secure Digital (SD) card	12, 547, 583
Selected altitude	53

Selected Altitude	439, 442, 446, 462
Selected Altitude Capture Mode	439
Selected Altitude Capture Mode (ALTS)	438, 442
Selected Altitude Intercept Arc	161
Selected course	49, 58
Selected Course	455, 457, 458
Selected heading	49, 58
Selecting a COM radio	100
Selecting a NAV radio	110
Sequencing, automatic	601
Service class	540
Servos	459
SIGMET	331
SiriusXM	
radio	278
Radio	539
Receiver troubleshooting	557
XM WX Satellite Weather	278
Activating	278
NEXRAD	288
SiriusXM channel list	541
SiriusXM radio	540
SiriusXM radio entertainment	129
SiriusXM radio volume	543
SiriusXM Satellite Radio	539, 541
SiriusXM weather/radio	4
Slip/Skid indicator	52
Softkeys	
LTNG	294
PFD	18–20
Speaker	125
Standby frequency	100, 103, 109
Standby frequency field	100
Standby Navigation Database	585, 587
Stereo headsets	125
Stormscope	359
Stormscope lightning data	22
Stuck microphone	131
Sunrise	241
Sunset	241
SVS	576
SVS troubleshooting	556
Symbols, map	605
Synthetic vision (SVS)	479, 480
System annunciations	17, 561, 563
System Display (EIS)	90–92
System message advisories	566
System power-up	13
System Setup Page	34
System Status Page	40
System time	35

T

TA	566
Tachometer	83–85, 87–89, 91–93
TAF	297, 332
TAS	566, 574
TAWS	580
TAWS-B	
System Status	392
Terminal procedures charts	500, 520
Terrain	568
Color indications	607
Terrain awareness and warning system (TAWS)	75
Terrain Proximity	364
Terrain-SVS	372
Timer	575
Departure	42
Flight	42
Timer, PFD generic	41
Time, system	35
TIS	394
TOD	263, 264, 270
TOPO DATA	145, 146, 155
Top of Descent	263, 264
TOPO SCALE	147
Track indicator	57
Traffic Advisory	566
Traffic annunciation	49, 74
Traffic information service (TIS)	
Voice alerts	74
Traffic Information Service (TIS)	603–604
Transponder code entry	123
Transponder data box	95
Transponder ground mode	120
Transponder softkeys	120
Transponder standby mode	121
Transponder VFR code	124
Trim adapter	459
Trip Planning	240, 241, 242
Trip statistics	43
Trip Statistics	241, 242
True airspeed	50
True Airspeed	242
Turbine Inlet Temperature (TIT)	83, 85, 87, 89
Turn anticipation	601
Turn rate indicator	60
TX indicator	101

U

Unable to display chart	500, 520
Updating Garmin databases	497
Updating Jeppesen databases	517

V

Vacuum Pressure-----	84–85, 91–92
VDI -----	264, 265
Vertical deviation -----	444
Vertical deviation guidance -----	226
Vertical Deviation Indicator -----	264
Vertical navigation-----	225
Direct-to -----	224
Vertical Navigation (VNV)	
Flight control-----	442–446
Vertical Path Tracking Mode (VPTH) -----	442–443, 467
Vertical speed -----	9
Vertical speed guidance-----	226
Vertical speed indicator-----	55
Vertical Speed Mode (VS)-----	439
Vertical Speed Reference -----	439
Vertical track-----	566
Video settings -----	553
Video system -----	479, 552
VNAV -----	189
VNV -----	263, 576, 598
VNV guidance	
Disabling -----	223
Enabling -----	223
VNV indications -----	72
VNV Target Altitude -----	442–445
VNV Target Altitude Capture Mode (ALTV) -----	446
Voice alerts, TIS-----	74
Voice alerts, TIS Traffic-----	398, 421
Voltmeter-----	84–85, 91–92
VOR	
Nearest -----	181–182
VOR selection-----	109
VS -----	9
VS-----	265
Vspeed references -----	49
VS TGT -----	225, 263

W

WAAS-----	247, 461, 598, 599
WARNING-----	562
Waypoint	
Automatic sequencing -----	601
Skipping -----	601
Waypoint Pages (WPT)-----	31
Waypoint Selection Submenu--	186, 193, 197, 198, 244
Weather (real-time)-----	4
Wind -----	136, 157
Wind data-----	49
Winds Aloft -----	334
WIND Softkey-----	301, 334
Wings level-----	450, 452

X

XM WX lightning-----	18, 22
XM WX Satellite Weather	
AIREPs -----	308
AIRMETs-----	331
Icing -----	306
PIREPs-----	308
SIGMETs -----	331
Turbulence-----	306, 307

Z

Zoom	
Auto-----	138



GARMIN®

Garmin International, Inc.
1200 East 151st Street
Olathe, KS 66062, U.S.A.
p:913.397.8200
f:913.397.8282

Garmin AT, Inc.
2345 Turner Road SE
Salem, OR 97302, U.S.A.
p:503.391.3411
f:503.364.2138

Garmin (Europe) Ltd.
Liberty House, Bulls Copse Road
Houndsdown Business Park
Southampton, SO40 9RB, U.K.
p:44/0870.8501241
f:44/0870.8501251

Garmin Corporation
No. 68, Jangshu 2nd Road
Shijr, Taipei County, Taiwan
p:886/02.2642.9199
f:886/02.2642.9099

www.garmin.com

